

PLS125

**verve**  
*design*

# PENDANT LAMP



## NOTE

- This product is intended for permanent connection to fixed wiring of the 230/240volt mains electrical supply system
- Installation must be carried out by a licensed electrical contractor
- Installation must adhere to local wiring rules and requirements of standard AS/NZS3000 Electrical Installations
- The product is for indoor use only

**Max lamp rating 60watt,  
E27 Edison Screw type base**

## INSTALLATION INSTRUCTIONS

### IMPORTANT!

**Ensure that the power is turned off to the circuit being worked on**

1. Select a mounting position. Avoid positions near vents where the air movement would cause the fitting to sway
2. Ideally the mounting bracket would be screwed into a solid member such as a ceiling joist or beam. If there is none at the mounting position consideration should be given to installing a supporting batten, or use of other suitable fixings that will support the weight of the light safely and adequately in the ceiling material.
3. Remove the packing material from the lamp. You may however find it a good idea to leave foam packaging over the main shade during installation to prevent breakage. Take care not to drop or knock the lamp as the shade is of glass.
4. Unscrew the nut to allow access to the mounting bracket. Fit the mounting bracket at the chosen location and check it is secure
5. Make any required adjustment to the cord restraint so that the shade hangs at the desired height. Ensure the cord restraint is placed hard against the back of the mounting bracket and the cord loops back through both holes so that the cord does not slip.
6. Complete the wiring of the cord to the mains supply using the terminal block provided. The earth wire to the mounting bracket must be connected to mains earth.
7. Check all connections

**KAYLA**

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE FIRST USE.

8. Refit the mounting cover by slipping it over the centre tube of the mounting bracket and tightening the nut to hold it in position
9. Remove any remaining packing/ protective covering, install a bulb
10. Restore power to circuit and test.


## CARE & CLEANING

Ensure fixture is turned off when replacing bulbs or cleaning. Allow to cool before handling.

Only replace bulbs with correct type, rating and size

Do not use harsh abrasive or solvent on any part of the fixture, clean only using dilute mild detergent on damp cloth.

Do not insert any object into lampholder or during cleaning.



## Warranty

Arlec guarantees this product in accordance with the Australian Consumer Law.

Arlec also warrants to the original first purchaser of this product ("you") from a retailer that this product will be free of defects in materials and workmanship for a period of 12 months from the date of purchase; provided the product is not used or installed other than for the purpose, or in a manner not within the scope of the recommendations and limitations, specified by Arlec, is new and not damaged at the time of purchase, has been properly installed by a licensed electrician or contractor who is licensed to install electrical products in the place in which the product was installed and in accordance with Arlec's installation instructions, has been maintained in accordance with the recommendations specified by Arlec, has not been subjected to abuse, misuse, neglect or damage, has not been modified or repaired without the approval of Arlec and has not been used for, or installed in premises which are used for, commercial purposes ("Warranty").

If you wish to claim on the Warranty, you must, at your own expense, return the product or that part of the product which you believe is defective in materials and workmanship, and provide proof of original purchase, your name, address and telephone number and a certificate of installation or other document required by law for the installation of electrical products in the place in which the product was installed issued by the licensed electrician or contractor who installed the product, to Arlec at the address below within 12 months from the date of purchase. Please note that the Warranty does not cover removal or re-installation of the product or that part of the product which you believe is defective.

Arlec will assess any claim you may make on the Warranty in the above manner and if, in Arlec's reasonable opinion, the Warranty applies, Arlec will at its own option and expense replace the product (or part of the product) with the same or similar product (or part of the product) or repair the product (or part of the product) and return it to you or refund the price you paid for the product. Arlec will bear its own expenses of doing those things, and you must bear any other expenses of claiming on the Warranty.

The Warranty is in addition to other rights and remedies you may have under a law in relation to the product to which the Warranty relates.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

# **ARLEC**

Arlec Australia Pty. Ltd. ACN 009 322 105 ("Arlec") gives the Warranty.

Arlec's telephone number, address and email address are:

Customer Service: (03) 9982 5111

Building 3, 31 – 41 Joseph Street, Blackburn North, Victoria, 3130

Blackburn North LPO, P.O. Box 1065, Blackburn North, 3130

Email: [custservice@arlec.com.au](mailto:custservice@arlec.com.au)