

ARLEC**e saver**

INTELLIGENT

Standby Power Adaptor For Chargers

QUICK START GUIDE:

➤ For first time use or changing to a different charger, please follow these steps:



1 Plug e-saver and charger to power outlet, **DO NOT** plug in phone or device being charged at this stage.



2 Press and hold the reset button on the e-saver for 3 seconds until the red LED light flashes **RAPIDLY**.



3 After approximately 1 minute, the red LED light will flash **SLOWLY**; now connect your phone or device being charged.



4 E-saver will automatically allow charging and power saving function to commence, this might take up to 15 minutes.

*For more info on learning function mode, please refer to instructions "Learning function mode set up" section. E-saver does not switch on instantly, when phone or charging appliance is connected; E-saver does not switch off instantly, when phone or charging appliance is charged. Please allow up to 15 minutes for e-saver to automatically switch on or off the charging appliance, or press reset button once to quick charge.


LEARNING FUNCTION MODE SET UP ➤

If the e-saver appears to be not to be working properly, it may cause by the e-saver programmed factory setting that does not compatible with the charger, but e-saver has a learning function mode that can adapt to different chargers.

To activate the learning function mode, please follow the following procedure:

1. Plug e-saver into a power point.
2. Plug the charger into e-saver; do not connect the device being charged (e.g. cell phone etc) at this moment.
3. Press and hold the reset button on e-saver for 3 seconds till the red LED light flashes rapidly, the e-saver is in learning function mode.
4. After 1 minute, the red LED light will flash slowly, now connect the device being charged (e.g. cell phone etc) to the charger.

5. The red LED light will stop flashing and stay on, e-saver will start the charging process. After the device being charged is fully charged, e-saver will cut off the electricity to the charger, the learning function mode is completed.



*Charger shown for illustrative purposes only and is not included.

TO BYPASS STANDBY MODE OR FOR INSTANT CHARGING, PRESS AND HOLD THE RESET BUTTON ON E-SAVER FOR 1 SECOND.

NOTE ➤

1. E-saver only suits chargers with a charging current of 1 amp DC or less. Please check the charger output DC current rating before connecting to the e-saver.
2. E-saver has built in overload protection, if your e-saver does not function, please check your charger DC output current rating to ensure that it is less than 1 amp DC.

IMPORTANT ➤ Please read these instructions carefully before first use.

ES001

ARLEC**e saver**

INTELLIGENT

Standby Power Adaptor For Chargers

E-saver has standby monitoring capability. When the charging appliance (e.g. cell phone etc...) is fully charged, e-saver will cut off the electricity to the charger and goes into standby mode. During standby mode, e-saver monitors the charging appliance once in every 10 minutes. If there is any need for charging, with appliance battery level lower than 80%, e-saver will automatically turn on and resume normal charging mode, indicated by a continuous red LED light.

SPECIFICATIONS >

Input: 240VAC 50Hz 80mA

Output: 240VAC 50Hz 20W

Standby Consumption: 0.02W

**DO NOT EXCEED TOTAL
MAXIMUM LOADING 20W**

**CHARGER CURRENT NOT
TO EXCEED 1 AMP DC**

Warranty >

Arlec guarantees this product in accordance with the Australian Consumer Law.

Arlec also warrants to the original first purchaser of this product ("you") from a retailer that this product will be free of defects in materials and workmanship for a period of 12 months from the date of purchase; provided the product is not used other than for the purpose, or in a manner not within the scope of the recommendations and limitations, specified by Arlec, is new and not damaged at the time of purchase, has not been subjected to abuse, misuse, neglect or damage, has not been modified or repaired without the approval of Arlec and has not been used for commercial purposes ("Warranty").

If you wish to claim on the Warranty, you must, at your own expense, return the product, and provide proof of original purchase and your name, address and telephone number, to Arlec at the address below or the retailer from whom you originally purchased the product within 12 months from the date of purchase.

Arlec will (or authorise the retailer to) assess any claim you may make on the Warranty in the above manner and if, in Arlec's reasonable opinion, the Warranty applies, Arlec will at its own option and expense (or authorise the retailer to) replace the product with the same or similar product or repair the product and return it to you or refund the price you paid for the product. Arlec will bear its own expenses of doing those things, and you must bear any other expenses of claiming on the Warranty.

The Warranty is in addition to other rights and remedies you may have under a law in relation to the product to which the Warranty relates.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For sales and product information telephone:

CUSTOMER SERVICE: (03) 9982 5111

Visit us at: www.arlec.com.au

MADE IN CHINA
CPIN002166/2

ES001

Due to continuous research and development the specifications in these instructions are subject to change without notice.