

ATL425CE

verve
design

CLAMP LAMP

This lamp is supplied with a 5W LED bulb that provides equivalent light output of a 35watt incandescent, but lower energy consumption.

The LED bulb can if desired be replaced with up to 35watt halogen incandescent bulb, but the lamp will run hotter.

WARNING! THE LAMP WILL GET HOT IN USE; AVOID CONTACT WITH THE HOT LAMP, ESPECIALLY DIRECT CONTACT WITH THE BULB.

BULB FITTING TOOL

A Suction cup tool is provided to assist in fitting bulbs, as it is difficult to grasp the bulb once positioned in the lamp body.


- 1 Press the suction cup onto the face of the GU10 bulb.
- 2 Then you can use the suction cup as a handle to insert or remove the bulb from the lamp base.
- 3 Remove the tool from bulb by lifting the edge of the cup to release.
- 4 Keep the tool in a safe place so that you have next time a bulb needs replacement.
- 5 **CAUTION!** Do not use tool on hot bulbs. Remove tool before operating light fixture.

NOTE: The exact type of suction cup tool may vary from the one shown here.



TO FIT / CHANGE THE BULB

To fit bulbs into lamp bases - using the fitting tool align the pins with holes in the lamp base, locate and rotate $\frac{1}{4}$ turn clockwise to engage. Remove the fitting tool.



5W
LED

CHROME

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE FIRST USE.

Before changing a bulb, switch off; disconnect the plug and let it cool for at least 10 minutes.

Replace it with a bulb of the same type (GU10 type bulb) , with a rating of 240volt and 5watt for LED tpe bulbs; or 240volt and no greater than 35watt max. for halogen incandescent bulbs.

TO REMOVE BULB

Ensure the lamp is unplugged and cooled. Using the bulb fitting tool, turn the old bulb $\frac{1}{4}$ turn anticlockwise and lift out of the lamp base.

INSTRUCTIONS FOR USE & CARE

- 1 Use the base clamp to fit to a stable object in a dry location.
- 2 Use the lamp indoors only.
- 3 Keep out of the reach of young children and pets.
- 4 **WARNING!** The lamp will get hot in use, especially when using incandescent bulbs - avoid contact with the hot lamp, especially direct contact with the bulb.
- 5 Use only GU10 type bulb of 240 volt rating 5W LED type recommended or 35watt maximum Halogen incandescent.
- 6 To clean the lamp use a clean dry cloth. Wait 10 minutes after disconnecting to allow time to cool.
- 7 The electrical parts can only be serviced by a qualified tradesman, in compliance with standards/ specifications.

Warranty

Arlec guarantees this product in accordance with the Australian Consumer Law.

Arlec also warrants to the original first purchaser of this product ("you") from a retailer that this product will be free of defects in materials and workmanship for a period of 12 months from the date of purchase; provided the product is not used other than for the purpose, or in a manner not within the scope of the recommendations and limitations, specified by Arlec, is new and not damaged at the time of purchase, has not been subjected to abuse, misuse, neglect or damage, has not been modified or repaired without the approval of Arlec and has not been used for commercial purposes ("Warranty").

If you wish to claim on the Warranty, you must, at your own expense, return the product, and provide proof of original purchase and your name, address and telephone number, to Arlec at the address below or the retailer from whom you originally purchased the product within 12 months from the date of purchase.

Arlec will (or authorise the retailer to) assess any claim you may make on the Warranty in the above manner and if, in Arlec's reasonable opinion, the Warranty applies, Arlec will at its own option and expense (or authorise the retailer to) replace the product with the same or similar product or repair the product and return it to you or refund the price you paid for the product. Arlec will bear its own expenses of doing those things, and you must bear any other expenses of claiming on the Warranty.

The Warranty is in addition to other rights and remedies you may have under a law in relation to the product to which the Warranty relates. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

ARLEC

Arlec Australia Pty. Ltd. ACN 009 322 105 ("Arlec") gives the Warranty.

Arlec's telephone number, address and email address are:

Customer Service: (03) 9982 5111

New Zealand Toll Free: 0800 003 329

Building 3, 31 – 41 Joseph Street, Blackburn North, Victoria, 3130

Blackburn North LPO, P.O. Box 1065, Blackburn North, 3130

Email: custservice@arlec.com.au