

TECHNICAL DATA**Specifications**

Input Voltage	230-240V AC, 50Hz
Supply Current	0.25A
Max Watt	55W
IP Classification	IP44
Power Factor	0.995
Replacement Globe	3U 55W Max Compact Fluorescent Lamp Arlec Part No: FT55
Protective Shield	Glass Lens (325 x 205 x 5mm thick) Arlec Part No. SS2039
Construction	
Enclosure	Zinc / Aluminium alloy
Glass / Lens	5mm thick tempered safety
Reflector	0.3mm aluminium
Colour	Blue

WARRANTY

Arlec guarantees this product in accordance with the Australian Consumer Law.

Arlec also warrants to the original first purchaser of this product ("you") from a retailer that this product will be free of defects in materials and workmanship for a period of 12 months from the date of purchase; provided the product is not used other than for the purpose, or in a manner not within the scope of the recommendations and limitations, specified by Arlec, is new and not damaged at the time of purchase, has not been subjected to abuse, misuse, neglect or damage, has not been modified or repaired without the approval of Arlec and has not been used for commercial purposes ("Warranty").

If you wish to claim on the Warranty, you must, at your own expense, return the product, and provide proof of original purchase and your name, address and telephone number, to Arlec at the address below or the retailer from whom you originally purchased the product within 12 months from the date of purchase.

Arlec will (or authorise the retailer to) assess any claim you may make on the Warranty in the above manner and if, in Arlec's reasonable opinion, the Warranty applies, Arlec will at its own option and expense (or authorise the retailer to) replace the product with the same or similar product or repair the product and return it to you or refund the price you paid for the product. Arlec will bear its own expenses of doing those things, and you must bear any other expenses of claiming on the Warranty.

The Warranty is in addition to other rights and remedies you may have under a law in relation to the product to which the Warranty relates.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

**For All Sales & Warranty Enquiries**

Arlec Australia Pty. Ltd. ACN 009 322 105
("Arlec") gives the Warranty.
Building 3, 31 – 41 Joseph Street,
Blackburn North, Victoria, 3130

Blackburn North LPO, P.O. Box 1065, Blackburn North, 3130

Customer Service: (03) 9982 5111

Email: custservice@arlec.com.au

© This instruction leaflet is subject to copyright and must not be reproduced, copied or otherwise used in any way or for any purpose without the consent in writing of the owner, Arlec Australia Pty Ltd (A.C.N. 009 322 105).

CPIN0002116/2

COOLTOUCH
energy efficient

55W FLUORESCENT WORKLIGHT

INSTRUCTIONS**WL550**

INTRODUCTION

The Ultra-Cool Portable 55W Compact Fluorescent Lamp (CFL) Worklight WL550 is suitable for indoor (ambient temperature 25°C) or temporary outdoor use. The worklight can be plugged into a standard power point and has a weatherproof classification of IP44.

OPERATION

Assemble the unit as shown in diagram. Fix support bracket onto base stand using the bolt, washer and wing nut. Ensure that the wing nut is tight and firmly holds the support bracket and base stand assembly.

Side wing knob allows adjustment of the tilt of the worklight body on the support bracket.

NOTE: The safety adjustment stop prevents worklight head from tilting too far forward.

This helps avoid accidental scorching or burning. Do not remove support bracket from worklight body.

When adjusting the worklight tilt, tighten the side wing knob with finger pressure only, do not over tighten.


While adjusting the lamp head avoid pinching or bending of the supply cord.

WARNING:

When the worklight is operated outdoors the supply plug must be appropriately covered or located such that it is subjected to indoor conditions only.

If the external flexible cable or cord of this worklight is damaged:

Contact the Arlec Customer Service Team (Refer to details on back page) or a similar qualified person in order to avoid hazard.



Easy adjustment of Lamp Head



Adjusting Wing Knob

INSTALLING CFL TUBE



1. The CFL tube is supplied and packed separately to avoid damage.
2. Ensure that worklight is unplugged from wall socket.
3. Open the worklight housing by releasing the toggle latches.
4. The glass front of the housing will hinge forward and down.
5. Insert the tube in the holder, ensuring that you do not touch the glass envelope of the tube with bare hands.
6. Close glass front.
7. Your worklight is now ready to use.

DO'S AND DONT'S

Please observe the following do's and don'ts to ensure safe and trouble free use:

DO use the handle to adjust the beam.

DO keep the worklight out of reach of children when in use.

DO switch off and allow to cool for a minimum of 10 minutes before storing.

DON'T stand worklight in pools of water.

DON'T handle with wet hands or operate when standing on wet surface.

DON'T allow power cable to come into contact with front of worklight or housing.

DON'T allow overhanging shrubs or foliage to come into contact with worklight.

DON'T place or operate the worklight closer than 5 metres to a swimming pool or spa.

DON'T operate the worklight with the front of housing opened.