

## Charging Power Bank

You can charge the power bank with a 5V USB power adaptor or via a computer.

**NOTE:** Do not charge and discharge the power bank at the same time. In this case the power bank would only charge its internal batteries and doesn't provide any charge to the external devices connected to its USB ports.



### Battery Bank does not power the USB device.

Either the battery bank is out of charge or the USB device is drawing more power than what the battery bank could supply. If the battery bank is fully charged check the specifications of the USB device you plugged in.

### Battery Bank does not work

Either the battery bank is out of charge or there has been a short circuit.

## Trouble Shooting

## Main Specifications

Model	AP4260
Battery type	Lithium-ion rechargeable cell
Input voltage	DC 5V
Input current	1A Max (varies according to the charge level)
Output current	1A and 2A Max
Output Voltage	5V (+/-0.25)
Rated capacity	3.6V/6000mAh

Charging time	7-8 Hours (with 1A charger)
Size	100x62x21 mm (+/-5)
Load Detection	Auto-detect the plug-in and plug-out of devices
Safety	OVP, OCP; Output OCP OVP, short protection.
Charging temperature	0°C - 45°C
Discharging temperature	Initial -10°C ~ +50°C
Weight	175g (+/-5)

Arlec guarantees this product in accordance with the Australian Consumer Law.

Arlec also warrants to the original first purchaser of this product ("you") from a retailer that this product will be free of defects in materials and workmanship for a period of 24 months from the date of purchase; provided the product is not used or installed other than for the purpose, or in a manner not within the scope of the recommendations and limitations, specified by Arlec, is new and not damaged at the time of purchase, has been properly installed by a licensed electrician or contractor who is licensed to install electrical products in the place in which the product was installed and in accordance with Arlec's installation instructions, has been maintained in accordance with the recommendations specified by Arlec, has not been subjected to abuse, misuse, neglect or damage, has not been modified or repaired without the approval of Arlec and has not been used for, or installed in premises which are used for, commercial purposes ("Warranty").

If you wish to claim on the Warranty, you must, at your own expense, return the product or that part of the product which you believe is defective in materials and workmanship, and provide proof of original purchase, your name, address and telephone number and a certificate of installation or other document required by law for the installation of electrical products in the place in which the

product was installed issued by the licensed electrician or contractor who installed the product, to Arlec at the address below within 24 months from the date of purchase. Please note that the Warranty does not cover removal or re-installation of the product or that part of the product which you believe is defective.

Arlec will assess any claim you may make on the Warranty in the above manner and if, in Arlec's reasonable opinion, the Warranty applies, Arlec will at its own option and expense replace the product (or part of the product) with the same or similar product (or part of the product) or repair the product (or part of the product) and return it to you or refund the price you paid for the product. Arlec will bear its own expenses of doing those things, and you must bear any other expenses of claiming on the Warranty.

The Warranty is in addition to other rights and remedies you may have under a law in relation to the product to which the Warranty relates.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

### ARLEC

Arlec Australia Pty. Ltd.  
ACN 009 322 105 ("Arlec") gives the Warranty.  
Arlec's telephone number, address and email address are:

Customer Service: (03) 9982 5111  
New Zealand Toll Free: 0800 003 329

Building 3, 31 - 41 Joseph Street, Blackburn  
North, Victoria, 3130  
Blackburn North LPO, P.O. Box 1065, Blackburn  
North, 3130

Email: [custservice@arlec.com.au](mailto:custservice@arlec.com.au)

## user guide

CPIN002946 100mm x 145mm



### ARLEC

## DUAL USB POWER BANK 6000mAh



### Includes

30cm Micro USB charge cable

CPIN002946

## Safety Precautions

- Before using the USB Battery Pack, please read the following warnings carefully and use the product according to the procedures described in this manual. Failure to follow the precautions mentioned may result in fire, explosion, or shock.
- Do not dismantle this product, or any of its parts.
- Operate between (0 to 40°C). Store between (-10 to 50°C).
- Lithium-ion batteries can be dangerous if you don't handle them properly. They will ignite, or explode when exposed to high temperatures. So, do not leave them in a car during hot weather or in direct sunlight.
- Do not put it in your pocket or under pillows while in use.
- Li-ion batteries have safety components that protect the cells inside from misuse, so do not drop, bend or puncture the product; dropping or bending the battery pack will compromise the safety features of the battery and may cause an explosion.
- Do not use the battery pack with wet hands or expose it to water/fire, it may result in fire or electrical shock.
- Store this product in a cool and dry environment when not in use.
- Please recycle USB Battery Pack in accordance with local environmental laws and regulations.

## Main Features



- Two Sockets, 1A and 2A
  - LED Torch
  - 6000mAh capacity (Average smart phone battery 1200-2000mAh)
  - Battery level indicator
- NOTE:** The USB cable that comes with the unit is for charging purpose only, it cannot be used for data transfer or synchronization.

1. Press the power button once to check the battery capacity, the blue LED's flash indicating the charge level.
2. Press and hold the power button for 3 Seconds to turn "ON" the LED torch, while the torch is "ON" press the power button again to activate the "FLASHING" function. Press and hold the power button for 3 seconds to turn "OFF" LED torch light.

## Button Function

user guide

## Charging your Devices

To maximize battery life span, charge the power bank fully before first use for 8 to 10 hours. It is normal for the USB Battery Pack to become warm during charging.

The Power bank has two outputs, one is a 1A socket and the other is a 2A socket.

Use the 2A socket for charging Tablets and the 1A socket ideal for charging smart phones.

The power bank has 6000mAh capacity. It has the capacity to fully charge an average smart phone 3\* times.

**\*NOTE:** If you are using battery intensive apps or features on your phone while using a power bank to charge it, you may not notice a big increase in the battery level because you are draining the battery at the same time. So the net difference will be less).



### Battery Capacity of Common Smart Phones and Tablets

SMART PHONES:		TABLETS:	
iPhone 6	1810mAh	iPad Air	8820mAh
iPhone 6 plus	2915mAh	iPad mini	6471mAh
iPhone 5s	1560 mAh	iPad	11560mAh
Samsung Galaxy S5	2800mAh	Nexus 10	9000mAh
Nexus 5	2300mAh	Galaxy Tab 10.1	6860mAh